

# Michigan Specialty Paper - Time, Temperature and Pressure Settings

— All Times, Temperatures and Pressures are approximate. Individual heat presses may vary. Testing is recommended. —

Product	Temperature	Time	Pressure	Peel
Jet Opaque	350°	30 sec	Medium	—
Jet Opaque (Thick Material - sweatshirts, etc.)	315° - Test	30 sec	Medium	—
Jet-Pro SofStretch	375°	30 sec	Heavy	Hot
Jet-Pro Active Wear	375°	20 sec	Medium	Hot
Koncert T's (2 Step) (See literature for specific instructions)	Step #1 - 250° Step #2 - 375°	Step #1 - 20 sec Step #2 - 25 sec	Step #1 - Med. Step #2 - Heavy	Cold
Laser 1 Opaque	350°	30 sec	Medium	Cold
MSP Weed Free Light (See literature for specific instructions)	330°	25 sec	Heavy	Cold
Soft Jet Light (Blue Back)	375° - 400°	25 - 30 sec	Medium	Hot or Cold
Techni-Print 4.0	375°	30 sec	Heavy	Hot
3G Jet-Opaque	350°	30 sec	Medium	Cold